




# WellAware Walk Through

**Summary:** This walk through will assist you with an overview of the map features in LIFT. It will show you how to see all your site locations and in different map formats.


[Click here for a video demonstration!](#)

## Maps Overview

Map views are available under the All Sites or created group level. The map tab does not show up when you are drilled down to a specific site. To view the map, click on your desired group and navigate to the Map tab.



Once on the maps tab, you will see blue pins indicating the location of all your installed sites. If you click on each pin, the name of the location will populate. You can also use the search bar to search for a specific site for quicker locating purposes. Use your mouse scroll bar to zoom in and out of the map. Click and drag with your mouse to move around the map.



You also have the ability to change the look of the map. Next to the search bar, click the drop-down option to change the view between satellite and classic map views.

